

TRULY®

MODE D'EMPLOI

Calculatrice de poche

Modèle 285

10 chiffres

Erreurs de fonctionnement

Remise à zéro

Appuyer sur la touche **CE/C** avant de commencer les opérations
Appuyer 2 fois sur la touche **CE/C** pour vider la mémoire du Grand Total
Hors des opérations, si le symbole E apparaît à l'écran, appuyez sur la touche **CE/C** et recommencez vos opérations

Division par zéro

Si vous divisez un nombre par zéro ou calculez un prix de vente en utilisant une marge de 100 %, une erreur s'affiche. Appuyez sur **CE/C** pour annuler.

Dépassement du nombre de chiffres

Si le résultat d'un calcul comporte trop de chiffres pour que la calculatrice puisse les afficher, elle indique une erreur. Les douze premiers chiffres du résultat avec la décimale sont décalés de 12 positions à gauche de sa position correcte.
Appuyez 2 fois sur **CE/C** pour corriger.

Remise à zéro

Appuyez sur **AC** pour effacer l'affichage, le Grand total et la mémoire.

P1

Calculs de base

Racine carrée $3.5^2 = 12.25$

AC 3.5 **x** 8 **=** 12.25

Réciproque $1/8 = 0.125$

AC 1 **÷** 8 **=** 0.125

Calcul avec constante

15 + 18 = 33 15 **+** 18 **=** 33

30 + 18 = 48 30 **=** 48

37 - 21 = 16 37 **-** 21 **=** 16

50 - 21 = 29 50 **=** 29

3.5 x 8 = 28 3.5 **x** 8 **=** 28

3.5 x 12 = 42 12 **=** 42

125 ÷ 5 = 25 125 **÷** 5 **=** 25

90 ÷ 5 = 18 90 **=** 18

P2

Pourcentage

Pourcentage $128 \times 15\% = 19.2$

AC 128 **x** 15 **%** 19.2

Pourcentage direct + $250 + 10\% = 275$

AC 250 **+** 10 **%** 275

Pourcentage direct - $198 - 15\% = 275$

AC 198 **-** 15 **%** 168.3

Ratio 30 de 120 = ? (25%)
(25%)

AC 30 **÷** 120 **%** 25

Fonction Grand Total

J'additionne 4 fois 9,8 et 3 fois 12,7. Quel est le total ?

Sous-total 4 x 9.8

AC 4 **x** 9.8 **=** GT 39.2

Sous-total 3 x 12.7

3 **x** 12.7 **=** GT 38.1

Pour effacer le Grand total, appuyez 2 fois sur **GT** puis sur **AC**

P3

Calcul avec mémoires

Utilisation des touches mémoires

5 x 6 **AC** 5 **x** 6 **M+** MEMORY 30

+ 3 + 12.7 3 **+** 12.7 **M+** MEMORY 15.7

- 48 ÷ 3 48 **÷** 3 **M-** MEMORY 16

29.7 **MRC** MEMORY 29.7

Pour effacer les touches mémoires, appuyez 2 fois sur **MRC** puis sur **AC**

Calcul de marge

Mon prix d'achat est de \$ 90. Je veux une marge de 25 %. Quelle est ma marge en valeur ?

AC 90 **÷** 25 **MU** 120

(prix de vente)

MU 30

(marge en valeur)

P4

Calcul de taxe

Comment entrer le taux ?

Appuyez sur **AC** puis sur **RATE**. Entrez le taux de 12.5

AC **RATE** **RATE** 0

(le symbole clignote)

12.5 **+TAX** (SET) **RATE** 125

(le taux s'affiche)

Ajout de taxe

Le prix d'un article non taxé est de 35\$. Calculez le prix taxé et le montant de la taxe.

AC 35 **+TAX** **+TAX** 39.375

(prix taxé)

+TAX **TAX** 4.375

(montant de la taxe)

Réduction de la taxe

Le prix d'un article est de 45\$. Calculez le prix non taxé et le montant de la taxe.

AC 45 **-TAX** **-TAX** 40

(prix non taxé)

-TAX **TAX** 5

(montant de la taxe)

Rappel du taux de taxe

Pour retrouver le taux enregistré, appuyez sur **RATE** puis **TAX-**

P5

FRANÇAIS

⚠ AVERTISSEMENTS

Evitez d'utiliser et d'entreposer la calculatrice dans des endroits exposés à des températures extrêmes, à une grande quantité de poussière et à de l'humidité.

Ne laissez jamais tomber la calculatrice et évitez les chocs.

N'essayez jamais d'ouvrir la calculatrice.

Utilisez un chiffon doux et sec pour nettoyer l'extérieur de la calculatrice.

⚠ PILE

Rangez les piles hors de portée des enfants.

Utilisez seulement le modèle de pile spécifique à la calculatrice.

Remplacez la pile tous les deux ans même si la calculatrice fonctionne normalement.

Une pile peut fuir et endommager la calculatrice.



♻ RECYCLAGE DU PRODUIT

Ce symbole indique que ce produit ne doit être jeté avec les autres déchets ménagers. La mise en rebut incontrôlée des déchets présentant des risques environnementaux et de santé publique, veuillez séparer vos produits usagés des autres déchets. Vous favoriserez ainsi le recyclage de la matière qui les compose dans le cadre d'un développement durable.

Distribué par :

Wonday - Allée des acacias - 63190 LEZOUX - France

email : contact@wonday.com - web : www.wonday.com



P6

TRULY®

Tax Caculator 10-Digit

Model No. 285
User's Guide

Clearing Errors and Overflows

Entry Errors

Press **CE/C** once to clear an entry you have just input.

Press **CE/C** two times to clear the calculator except the independent memory and Grand Total memory.

Division by zero

If you divide a number by zero, or calculate a selling price using a margin of 100%, an error occurs and the error indicator "E" appears on the display.. Press **CE/C** to clear the error.

Overflow

An overflow occurs if the result of a calculation has too many digits for the calculator to display. The calculator displays the error indicator "E" and the first twelve digits of the result with the decimal shifted 12 places to the left of its correct position. Press **CE/C** two times to clear the error and display.

Clearing the calculator

Press **AC** to clear the display, Grand Total memory, and independent memory.

P1

Basic Calculations

Square $3.5^2 = 12.25$

AC 3.5 **x** **=** 12.25

Reciprocal $1/8 = 0.125$

AC 1 **÷** 8 **=** 0.125

Calculating with a constant

$15 + 18 = 33$ 15 **+** 18 **=** 33

$30 + 18 = 48$ 30 **=** 48

$37 - 21 = 16$ 37 **-** 21 **=** 16

$50 - 21 = 29$ 50 **=** 29

$3.5 \times 8 = 28$ 3.5 **x** 8 **=** 28

$3.5 \times 12 = 42$ 12 **=** 42

$125 \div 5 = 25$ 125 **÷** 5 **=** 25

$90 \div 5 = 18$ 90 **=** 18

P2

Percentage Calculations

Percent $128 \times 15\% = 19.2$

AC 128 **x** 15 **%** 19.2

Add on $250 + 10\% = 275$

AC 250 **+** 10 **%** 275

Discount $198 - 15\% = 275$

AC 198 **-** 15 **%** 168.3

Percent ratio 30 is what percent of 120? (25%)

AC 30 **÷** 120 **%** 25

P3

Using Grand Total Memory

You need the subtotals of 4 items at 9.8 and 3 items at 12.7 and their grand total.

Subtotal of 4 x 9.8 **GT** 39.2

Subtotal of 3 x 12.7 **GT** 38.1

Grand total **GT** 77.3

Clearing GT memory Press **GT** two times to clear the GT memory or press **AC** to clear the calculator.

Using Independent Memory

Use the memory keys to perform the following calculations.

5×6 **AC** 5 **x** 6 **M+** **MEMORY** 30

$+ 3 + 12.7$ 3 **+** 12.7 **M+** **MEMORY** 15.7

P4

Clearing memory Press **MRC** two times to clear the independent memory or press **AC** to clear the calculator.

Clearing memory Press **MRC** two times to clear the independent memory or press **AC** to clear the calculator.

Markup Calculations

Calculating selling price and profit amount

An item costs you \$90. You want to make a 25% profit. Calculate the selling price and the profit amount.

AC 90 **÷** 25 **MU** 120

(Selling price)

MU 30

(Profit amount)

Tax Calculations

Setting tax rate Pressing **AC** followed by **RATE** activates the tax rate setting mode. Let us set the tax rate at 12 5%

P5

AC **RATE** **RATE** 0
(Blinking to wait for setting rate)
12.5 **+TAX** (SET) **RATE** 125
(Rate set)

Tax add on The price of an item before tax is \$35. Calculate the price with tax and the tax amount.

AC 35 **+TAX** **+TAX** 39.375
(Price with tax)

+TAX **TAX** 4.375
(Tax amount)

Tax reduction The price of an item with tax is \$45. Calculate the price without tax and the tax amount.

AC 45 **-TAX** **-TAX** 40
(Price without tax)

-TAX **TAX** 5
(Tax amount)

Recalling tax rate Pressing **RATE** followed by **-TAX** (RECALL) to recall the current tax rate.

P6

ENGLISH

WARNING

Avoid use and storage of the calculator in areas subjected to temperature extremes and large amounts of humidity and dust. Do not subject the calculator to excessive impact, pressure or bending. Never try to open the calculator. Use a soft, dry cloth to clean the exterior of the calculator.

BATTERY

Keep batteries out of the reach of small children. Use only the type of battery specified for this calculator. Even if the calculator is operating normally, replace the battery at least once every two years. A battery can leak causing damage the calculator.

RECYCLAGE DU PRODUIT

This symbol indicates that this product should not be disposed of with other household waste. Uncontrolled disposal of waste with environmental and public health risks, please separate your used products from other waste. You will thus promote the recycling of the material which composes them within the framework of a sustainable development.

Distributed by:
Wonday - Allée des acacias - 63190 LEZOUX - France
email : contact@wonday.com - web : www.wonday.com

P7