

Exemple	TAB		Opération	Affichage écran
	A	B		
25 x 5 -) 84 ÷ 3 +) 68 + 17 182	Free	F	MC 25 [X] 5 [M+] 84 [÷] 3 [M] 68 [÷] 17 [M+] MR MC	MEMORY 125. MEMORY 28. MEMORY 85. MEMORY 182. 182.
123478 ÷ 5	Free	F	123456 ▶ ▶ 78 [+] 5 [=]	123 456. 1 234. 123 478. GRAND TOTAL 123 483.
456 + 378	Free	F	456 [÷] 365 [CE] 378 [=]	0. 378 GRAND TOTAL 834.
32 x 5 + 4 - 6 79 ÷ 2 - 30 ÷ 88 175 + 3	Free	F	ON/C 32 [X] 5 [÷] 4 [-] 6 [=] 79 [÷] 2 [-] 30 [÷] 88 [=] 175 [÷] 3 [=] GT	0. GRAND TOTAL 158. GRAND TOTAL 97.5 GRAND TOTAL 178. 433.5

Exemple	TAB		Opération	Affichage écran
	A	B		
100+50-30 (-10)x20÷0.5=	Free	F	ON/C 100 [÷] 50 [-] 30 [=] 10 [÷] 20 [÷] 0.5 [=]	0. GRAND TOTAL 120. GRAND TOTAL -400.
5000÷3=	↑	2	50 [00] [÷] 3 [=]	GRAND TOTAL 1'666.67
5000÷3=	5/4	2	50 [00] [÷] 3 [=]	GRAND TOTAL 1'666.67
5000÷3=	↓	2	50 [00] [÷] 3 [=]	GRAND TOTAL 1'666.66
\$12.34 34.56 - 56.78 78.90 \$69.02	Free	A	1234 [÷] 3456 [-] 5678 [÷] 7890 [÷]	12.34 46.90 -9.88 69.02
1234567890 x 66666=	Free	F	1234567890 [X] 66666 [=] ON/C ([AC] or [ON]) CE	ERROR 82.3037029547 82.3037029547 0.
√9 X 5	Free	F	9 [✓] [X] 5 [=]	GRAND TOTAL 15.
• 10% of 1500			15 [00] [X] 10 [%]	GRAND TOTAL 150.
5% add-on of 1500 (1500+5%=)			15 [00] [÷] 5 [%]	1575.
(1500-5%=)			15 [00] [-] 5 [%]	1425.
• percentage of 20 against 500			20 [÷] 5 [00] [%]	4. (%)
368+97+97=			368 [÷] 97 [=]	GRAND TOTAL 562.
839-47-47-47=	5/4	F	839 [-] 47 [-] [=]	698.
5 ⁻⁴ =			5 [÷] [=] [=]	0.0016
22.5 ⁼ =			22.5 [X] [=]	11'390.625

356000000002002

TRULY®

Mode d'emploi

Calculatrice de bureau

Modèle 661-12

12 chiffres

A FONCTION DES TOUCHES :

- [OFF] : Touche éteindre
 [AC] : Tout effacer
 [ON/C] : Touche marche/effacer/annuler
 [+/-] : Touche de changement de signe en positif ou négatif de la valeur affichée.
 [▶] : Touche correction rapide (suppression du chiffre de droite).
 [1] [2] [3] [4] [5] [6] [7] [8] [9] [0] [00] [.] : Touches de numération
 [+], [-], [X], [÷], [=], [←], [%] : Touches d'opération
 [M+] : Touche mémoire plus (permet d'ajouter le nombre affiché sur l'écran au chiffre en mémoire).
 [M-] : Touche mémoire moins (permet de soustraire le nombre affiché sur l'écran au chiffre en mémoire).
 [MR] : Rappel de mémoire (permet d'afficher le contenu de la mémoire).
 [MC] : Effacer le contenu de la mémoire
 [GT] : Fonction Grand Total : permet d'afficher le cumul des résultats lors de l'utilisation des signes = et %. Si on appuie deux fois, on obtient le total général.
 [00] : Ajout rapide de deux zéros

B AFFICHAGE ECRAN :

- GT : Grand Total
 M (MEMORY) : Mémoire indépendante
 - (MINUS) : Signe négatif
 E (ERROR) : L'écran indique ERROR lorsque le nombre de chiffres à afficher dépasse le nombre maximal de caractères affichables sur l'écran

- Appuyer sur [AC] pour effacer toutes les valeurs.
- Appuyer sur CE pour supprimer ERROR. Si la valeur sur l'écran n'apparaît plus elle peut être encore stockée en mémoire ou dans le grand total.

C CHANGER LA PILE :

- Cette gamme de calculatrice dispose de deux sources d'énergie :
1 l'énergie solaire
2 la pile 1.5 V
- L'arrêt automatique de la calculatrice s'opère au bout de 8 minutes.
- Si l'écran devient flou, cela signifie que l'alimentation est faible. Utilisez l'énergie solaire ou changez la pile.



FRANÇAIS

⚠ AVERTISSEMENTS

Évitez d'utiliser et d'entreposer la calculatrice dans des endroits exposés à des températures extrêmes, à une grande quantité de poussière et à de l'humidité.
Ne laissez jamais tomber la calculatrice et évitez les chocs.
N'essayez jamais d'ouvrir la calculatrice.
Utilisez un chiffon doux et sec pour nettoyer l'extérieur de la calculatrice.

⚠ PILE

Rangiez les piles hors de portée des enfants.
Utilisez seulement le modèle de pile spécifique à la calculatrice.
Remplacez la pile tous les deux ans même si la calculatrice fonctionne normalement.
Une pile peut fuir et endommager la calculatrice.



♻ RECYCLAGE DU PRODUIT

Ce symbole indique que ce produit ne doit être jeté avec les autres déchets ménagers. La mise en rebut incontrôlée des déchets présentant des risques environnementaux et de santé publique, veuillez séparer vos produits usagés des autres déchets. Vous favoriserez ainsi le recyclage de la matière qui les compose dans le cadre d'un développement durable.

Distribué par Safetool SASU :
ZI chez Cotte – BP1
63650 La Monnerie – France
Tél : +33(0)4 73 51 40 06
Mail: direct@safetool.fr
Web: safetool.fr

Example	TAB		Operation	Display
	A	B		
25 x 5 -) 84 ÷ 3 +) 68 + 17 182	Free	F	MC 25 X 5 = MEMORY 125. 84 ÷ 3 = MEMORY 28. 68 + 17 = MEMORY 182. MR MC	125. 28. 85. 182. 182.
123478 + 5	Free	F	123456 ▶ ▶ 78 + 5 = GRAND TOTAL 123483.	123'456. 1'234. 123'478. GRAND TOTAL 123'483.
456 + 378	Free	F	456 + 365 = 378 = GRAND TOTAL 834.	0. GRAND TOTAL 834.
32 x 5 + 4 - 6 79 + 2 - 30 + 88 175 + 3	Free	F	ON/C 32 X 5 + 4 - 6 = GRAND TOTAL 158. 79 + 2 - 30 + 88 = GRAND TOTAL 97.5 175 + 3 = GRAND TOTAL 433.5 GT	0. 158. 97.5 178. 433.5

Example	TAB		Operation	Display
	A	B		
100+50-30 (-10)x20÷0.5=	Free	F	ON/C 100 + 50 - 30 = GRAND TOTAL 120. 10 ÷ 20 × 0.5 = GRAND TOTAL -400.	0. 120. -400.
5000 ÷ 3 = 5000 ÷ 3 = 5000 ÷ 3 =	↑ 5/4 ↓	2 2 2	50 00 ÷ 3 = GRAND TOTAL 1'666.67 50 00 ÷ 3 = GRAND TOTAL 1'666.67 50 00 ÷ 3 = GRAND TOTAL 1'666.66	1'666.67 1'666.67 1'666.66
\$12.34 34.56 - 56.78 78.90 \$69.02	Free	A	1234 + 12.34 3456 - 56.78 5678 + 7890 + 69.02	12.34 46.90 -9.88 69.02
1234567890 x 66666=	Free	F	1234567890 X 66666 = ERROR 82.3037029547 82.3037029547 0. ON/C (AC or ON)	ERROR 82.3037029547 82.3037029547 0.
√9 X 5	Free	F	9 √ X 5 = GRAND TOTAL 15.	15.
• 10% of 1500 5% add-on of 1500 (1500+5%=) (1500-5%=) • percentage of 20 against 500			15 00 X 10 % GRAND TOTAL 150. 15 00 + 5 % 1575. 15 00 - 5 % 1425. 20 ÷ 5 00 % 4. (%)	150. 1575. 1425. 4. (%)
368+97+97= 839-47-47-47= 5 ⁻⁴ = 22.5 ³ =	5/4	F	368 + 97 = 839 - 47 = 5 + = 22.5 X = GRAND TOTAL 562. 698. 0.0016 11'390.625	562. 698. 0.0016 11'390.625

356000000002002

TRULY®

Electronic Calculator User's Manual

A KEY OPERATIONS:

- OFF

 : Power off

AC

 : All Clear

ON/C

 : Power On / Clear / Clear Error

+/-

 : Sign change key (Change the sign of the displayed value from positive to negative, or vice versa.)

▶

 : Right shift key (Shifts the displayed value to the right, deleting the rightmost digit.)

1

 ~

9

0

00

.

 : Numeral key

+

-

X

÷

=

√

%

 : Function key

M+

 : Memory plus (Adds the displayed value to the independent memory).

M-

 : Memory minus (Subtracts the displayed value from the independent memory).

MR

 : Memory recall (Effective before pressing

MC

 key).

MC

 : Memory Clear.

GT

 : Grand Total, Results are accumulated in the grand total by depressing the

=

 or

%

 key pressed once, it recalls the grand total. If pressed twice successively, it clears the grand total.

00

 : Fast addition of "0" (Displays two "0" when pressed once).

B LCD DISPLAY :

- GT : Grand Total
M (MEMORY) : Independent memory
- (MINUS) : Negative vice
E (ERROR) : The display shows "ERROR" when the answer exceeds the maximum number of display.

- Press

AC

 to clear all values.
- Press the

CE

 key to clear the "ERROR" but the value on the display is still effective,

MR

 &

GT

 are still stored.

C HOW TO CHANGE THE BATTERY:

- ❖ The product series adopt two power:
① Solar energy ② battery (1.5V)
Or adopt power of 1.5V battery.



- ❖ Auto Power-off : After approximately 8 minutes.
❖ When the display becomes blur, this indicates the battery power is nearly gone. You can use solar energy for power or replace the battery to make the display clear again.

ENGLISH

⚠ WARNING

Avoid use and storage of the calculator in areas subjected to temperature extremes and large amounts of humidity and dust.
Do not subject the calculator to excessive impact, pressure or bending.
Never try to open the calculator.
Use a soft, dry cloth to clean the exterior of the calculator.

⚠ BATTERY

Keep batteries out of the reach of small children.
Use only the type of battery specified for this calculator.
Even if the calculator is operating normally, replace the battery at least once every two years.
A battery can leak causing damage the calculator.



♻ PRODUCT RECYCLING

This symbol indicates that this product should not be disposed of with other household waste. Uncontrolled disposal of waste with environmental and public health risks, please separate your used products from other waste. You will thus promote the recycling of the material which composes them within the framework of a sustainable development.

Distributed by Safetool SASU :
ZI chez Cotte – BP1
63650 La Monnerie – France
Tel : +33(0)4 73 51 40 06
Mail. direct@safetool.fr
Web. safetool.fr