



MODE D'EMPLOI POUR SERRURE À COMBINAISON

Vous pouvez définir votre propre combinaison en suivant les instructions suivantes.

La combinaison d'origine 0-0-0.







4. Déplacez le bouton de remise à zéro à la position A. Le verrou s'ouvre avec votre nouvelle combinaison. Pour modifier de nouveau votre combinaison, reprendre ces étapes.


COMBINATION CODE LOCK INSTRUCTION HOW TO SET YOUR OPENING COMBINATION

You can set our own personal combination by following these instructions.

The opening combination is preset at 0-0-0.

- 1. Turn the dial to the preset combination 0-0-0.
- 2. Move the reset button to position B as shown in picture 1.

 The reset button is inside the cash box on the back on the lock mechanism.
- 3. Turn the dials to set your desired combination by holding the lever firmly in position B, and write dowm immediately.
- 4. Move the reset button back to position A. The lock will now open to your own combination. To change your combination repeat steps 1-4 above.





Service Consommateurs: Allée des acacias - 63190 LEZOUX - France - email: contact@wonday.com - web: www.reskal.com