**TRULY®**

MODE D'EMPLOI
Calculatrice de Bureau
Modèle 812-A-12
12 chiffres

## 1 Indications écran

- [ON/C] Touche marche/éteindre
- [AC] Tout effacer
- [CE] Erreur
- [►] Touche majuscule
- [MU] Effacer le dernier chiffre de l'entrée ou calculer le nombre.
- [GT] Rappel du grand total/Effacement du grand total
- [M+] Touche mémoire plus
- [M-] Touche mémoire moins
- [MR] Rappel de mémoire
- [MC] Effacer mémoire
- [MRC] Combinaison des touches MR et MC. Première pression pour MR et la seconde pour MC.
- [OFF] Touche arrêt. La calculatrice s'éteint automatiquement après 5 minutes d'inactivité.

NB : Quand il y [ON/C] a plus de 12 chiffres, l'erreur s'affiche. Appuyez sur ON

## 2 Fonctionnalités

Pour une suite rapide de chiffres, évitez les espaces inutiles ou les arrêts durant la saisie.
Appuyer longuement sur la première touche sans relâchement, tout en appuyant sur la deuxième touche.
Lorsque la première touche est relâchée, le chiffre de la deuxième touche a été entré.



Appuyez sur la première touche — 1.
Continuez d'appuyer sur la première touche — 1.
Relâchez la première touche, continuez en appuyant longuement sur la deuxième touche — 12.

## 3 Description

### (1)Curseur A

↑ (UP) : Arrondir à la hausse
↓ (CUT) : Arrondir à la baisse
5/4 : non arrondi

### (2)Curseur B

F : virgule flottante
4 : 4 chiffres après la virgule
2 : 2 chiffres après la virgule
0 : aucun chiffre après la virgule
+ : choisir le nombre de chiffres après la virgule, appuyez sur [•]

**Notes :** Sur les modèles sans les deux touches ci-dessus, le résultat calculé est affiché sous forme de décimale flottante.



## 4 Exemples

### 1 Arithmétique

Exemple

| Arithmétique | Opération | Ecran |
|---|---|---|
| (1) (12+34)×5÷3÷76.66..... | AC | 0. |
| sélecteur sur F | 12 | 12. |
| | 34 × | 46. |
| | 5 ÷ | 230. |
| | 3 | GRAND TOTAL 76.6666666666 |
| (2) 20÷3÷6.6666 | AC | 0. |
| sélecteur A sur "↓" et | 20 ÷ | 20. |
| sélecteur B sur 4 | 3 | GRAND TOTAL 6.6666 |
| (3) 20÷6÷3.34 | AC | 0. |
| sélecteur A sur "↑" et | 20 ÷ | 20. |
| sélecteur B sur "2" | 6 | GRAND TOTAL 3.34 |
| (4) 20÷6÷3 | AC | 0. |
| sélecteur A sur "5/4" et | 20 ÷ | 20. |
| sélecteur B sur "0" | 6 | GRAND TOTAL 3. |
| (5) 12.34+45.67" 23.45" 34.56 | AC | 0. |
| sélecteur A sur "5/4" et | 1234 | 12.34 |
| sélecteur B sur "+" | 4567 | 58.01 |
| | 2345 | GRAND TOTAL 34.56 |



## 2 Puissance

Curseur A sur 5/4 et curseur B sur 2.
Exemples

| | | |
|---|---|---|
| (1) $5^2$" 5×5×25 | AC | 0. |
| | 5 × | 5. |
| | | GRAND TOTAL 25.00 |
| (2) $\sqrt{5}$ 2.23606797749 | AC 5 √ | 2.23606797749 |
| | | GRAND TOTAL 2.24 |

## 3 Pourcentage

Exemple

| Arithmétique | Opération | Ecran |
|---|---|---|
| (1) 40×40%×16 | AC | 0. |
| | 40 × | 40. |
| | 40 % | GRAND TOTAL 16.00 |
| (2) 40÷3%÷1333.33 | AC | 0. |
| | 40 ÷ | 40. |
| | 3 % | GRAND TOTAL 1333.33 |
| (2) 100÷(100×15%)×115 | AC | 0. |
| | 100 × | 100. |
| | 15 % | GRAND TOTAL 15.00 |
| | | GRAND TOTAL 115.00 |



| Arithmétique | Opération | Ecran |
|---|---|---|
| (2) 100×(100×15%)×85 | AC | 0. |
| | 100 × | 100. |
| | 15 % | GRAND TOTAL 15.00 |
| | | GRAND TOTAL 85.00 |

## 4 Mémoire

Exemple

| Arithmétique | Opération | Ecran |
|---|---|---|
| (10×3)+(4×6)×(3÷4)÷39.25 | AC | 0. |
| | 10 × | 10. |
| | 3 M+ | GRAND TOTAL 30.00 |
| | 4 | GRAND TOTAL 4. |
| | 6 M+ | GRAND TOTAL 10.00 |
| | 3 ÷ | GRAND TOTAL 3. |
| | 4 M- | GRAND TOTAL 0.75 |
| | MR | GRAND TOTAL 39.25 |
| | MC | 39.25 |

NB : 1 pression sur la touche MRC déclenche la fonction MR et 2 pressions la fonction MC



## 5 Calcul Grand Total

Exemple

| Arithmétique | Opération | Ecran |
|---|---|---|
| (1) 0.15+0.12÷0.27 | AC | 3. |
| | 0.15 | 0.15 |
| | 0.12 | GRAND TOTAL 0.27 |
| (2) 7×60%×4.2 | × | GRAND TOTAL 7. |
| | 60 % | GRAND TOTAL 4.2 |
| (3) 50÷2÷25 | 50 ÷ | GRAND TOTAL 50. |
| | 2 | GRAND TOTAL 25.00 |
| (4) 0.78 0.2 0.58 | 0.78 | GRAND TOTAL 0.78 |
| | 0.2 | GRAND TOTAL 0.58 |
| | GT | GRAND TOTAL 30.05 |
| (1) (2) (3) (4) 30.05 | AC | GRAND TOTAL 0. |

## 6 Fonction permanente

Exemple

| Arithmétique | Opération | Ecran |
|---|---|---|
| (1) 5 6 11 ( 6 is constant ) | AC 5 | 5. |
| | 6 | GRAND TOTAL 11.00 |
| 9 6 15 | 9 | GRAND TOTAL 15.00 |
| 47 6 53 | 47 | GRAND TOTAL 53.00 |



| Arithmétique | Opération | Ecran |
|---|---|---|
| (2) 15 8 7 ( 8 is constant ) | AC 15 | 15. |
| | 8 | GRAND TOTAL 7.00 |
| 90 8 82 | 90 | GRAND TOTAL 82.00 |
| 41 8 33 | 41 | GRAND TOTAL 33.00 |
| (3) 27÷3÷9 ( 3 is constant ) | AC 27 ÷ | 27. |
| | 3 | GRAND TOTAL 9.00 |
| 330÷3÷110 | 330 | GRAND TOTAL 110.00 |
| 58.8÷3÷19.6 | 58.8 | GRAND TOTAL 19.60 |

## 7 Calcul du taux de marge

Exemple : Le prix d'un article est de 100€. Calculez le prix de vente. Si le bénéfice est de 30 %, quel est le prix de vente ? De combien est le bénéfice ?
(la touche [×] sera utilisée)

| | | |
|---|---|---|
| 100÷(1 30%)×142.86 ( prix de vente) | 27 AC | 0. |
| 142.86×100×42.86 ( bénéfice) | 100 | 100. |
| 42.86÷142.86÷30% | 30 MU | 142.86 |
| | MU | 42.86 |



Calcul du coût. Si le bénéfice est de 30 %, quel sera le prix de vente ?
(la touche [×] sera utilisée)

| | | |
|---|---|---|
| 100×(1 30%)×130 ( prix de vente) | | |
| 130×100×30 ( bénéfice) | AC | 0. |
| 30÷100÷30% | 100 × 30 MU | 130.00 |

## 8 Fonction de correction

| Arithmétique | Opération | Ecran |
|---|---|---|
| 123×456÷(-78) 719.08 | 5 AC | 0. |
| | 123 × | 123. |
| | 445(wrong) | 445. |
| | 47 CE | 0. |
| | 15 ÷ | 56088. |
| | 77(wrong) | 77. |
| | ► | 7. |
| | 8 / | -78. |
| | | GRAND TOTAL -719.08 |
| | ► | GRAND TOTAL -719.00 |
| | OFF | |

NB : [CE] efface le nombre entier,
[►] efface le dernier chiffre

Remarque : Si la description des fonctions de certains modèles n'est pas identique à celle du manuel de l'utilisateur, veuillez tenir compte des fonctions réelles de l'appareil.



## FRANÇAIS

### ⚠ AVERTISSEMENTS

Evitez d'utiliser et d'entreposer la calculatrice dans des endroits exposés à des températures extrêmes, à une grande quantité de poussière et à de l'humidité.
Ne laissez jamais tomber la calculatrice et évitez les chocs.
N'essayez jamais d'ouvrir la calculatrice.
Utilisez un chiffon doux et sec pour nettoyer l'extérieur de la calculatrice.

### ⚠ PILE

Rangez les piles hors de portée des enfants.
Utilisez seulement le modèle de pile spécifique à la calculatrice.
Remplacez la pile tous les deux ans même si la calculatrice fonctionne normalement.
Une pile peut fuir et endommager la calculatrice.

### RECYCLAGE DU PRODUIT

Ce symbole indique que ce produit ne doit être jeté avec les autres déchets ménagers. La mise eu rebut incontrôlée des déchets présentant des risques environnementaux et de santé publique, veuillez séparer vos produits usagés des autres déchets. Vous favoriserez ainsi le recyclage de la matière qui les compose dans le cadre d'un développement durable.

FR NOTICE

Distribué par : Wonday - Allée des acacias
63190 LEZOUX - France
email : contact@wonday.com
web : www.wonday.com

FR
Cette calculatrice et ses piles se recyclent
À DÉPOSER EN MAGASIN OU À DÉPOSER EN DÉCHÈTERIE

Points de collecte sur www.quefaireducmesdechets.fr
Privilégiez la réparation ou le don de votre appareil !

**TRULY®**

# NORMAL Calculator
# Instruction Manual

## 1.MAIN KEY FEATURES

| | |
|---|---|
| ON/C | Power/Clear key |
| AC | Clear all |
| CE | Clear error |
| ► | Shift key. Clear the last digit of input or calculating number |
| MU | Mark up. Price mark up |
| GT | Grand total memory recall/Grand total memory clear |
| M | Memory plus key |
| M | Memory minus key |
| MR | Memory recall |
| MC | Memory clear |
| MRC | Combination of MR and MC keys. First press is MR function, second press is MC function. |
| OFF | Power off key. Calculator will be power off automatically after idle state in 5 minutes. |

Notes:

When the inputing digits are more than 12, "ERROR" will show up.
Press ON/C or ► to input new digits.

## 2.LONG PRESSING FEATURE

For fast input digits with multi-fingers, avoid unnecessary gap or stop when inputting the digits. Long press the first key without release, at the same time, able to press the second key. When the first key is released, the digit of second key has been inputted.

| | |
|---|---|
| (1) Press the first key | 1. |
| (2) Keep pressing the first key | 1. |
| (3) Release the fist key, go on with long pressing the second key | 12. |



## 3.SWITCHING DESCRIPTION

(1) TAB-A

↑(UP) : Rounding up
↓(Cut) : Rounding cut
5/4 : Rounding off

(2) TAB-B

F : Floating decimal point.
4 : Select 4 decimal places
2 : Select 2 decimal places
0 : Select 0 decimal places
+ : Auto add a decimal point and two decimal places to all inputted values, unless press •

Notes: On the models without above two keys, calculated result is shown as floating decimal.

## 4. Examples

### 1. Arithmetic

| Arithmetic | Operation | Display |
|---|---|---|
| Example | | |
| (1) (12+34)×5÷3÷76.66..... | AC | 0. |
| ( TAB-A is set on "F" ) | 12 | 12. |
| | 34 × | 46. |
| | 5 ÷ | 230. |
| | 3 | GRAND TOTAL 76.666666666 |



| Arithmetic | Operation | Display |
|---|---|---|
| (2) 20÷3÷6.6666 | AC | 0. |
| TAB-A is set on "↓", and TAB-B is set on "4" | 20 ÷ | 20. |
| | 3 | GRAND TOTAL 6.6666 |
| (3) 20÷6÷3.34 | AC | 0. |
| TAB-A is set on "↑", and TAB-B is set on "2" | 20 ÷ | 20. |
| | 6 | GRAND TOTAL 3.34 |
| (4) 20÷6÷3 | AC | 0. |
| TAB-A is set on "5/4", and TAB-B is set on "0" | 20 ÷ | 20. |
| | 6 | GRAND TOTAL 3. |
| (5) 12.34+45.67" 23.45" 34.56 | AC | 0. |
| TAB-A is set on "5/4", and TAB-B is set on "+" | 1234 | 12.34 |
| | 4567 | 58.01 |
| | 2345 | GRAND TOTAL 34.56 |

### 2.Power and evolution operation

TAB-A is set on "5/4", and TAB-B is set on "2".
( Below are the examples with such setting)

Example

| | | |
|---|---|---|
| (1) $5^2$" 5×5×25 | AC | 0. |
| | 5 × | 5. |
| | | GRAND TOTAL 25.00 |



| Arithmetic | Operation | Display |
|---|---|---|
| (2) √5 2.23606797749 | AC 5 √ | 2.23606797749 |
| | | GRAND TOTAL 2.24 |

### 3.Percent operation

Example

| | | |
|---|---|---|
| (1) 40×40%×16 | AC | 0. |
| | 40 × | 40. |
| | 40 % | GRAND TOTAL 16.00 |
| (2) 40÷3%÷1333.33 | AC | 0. |
| | 40 ÷ | 40. |
| | 3 % | GRAND TOTAL 1333.33 |
| (2) 100÷(100×15%)×115 | AC | 0. |
| | 100 × | 100. |
| | 15 % | GRAND TOTAL 15.00 |
| | | GRAND TOTAL 115.00 |
| (2) 100×(100×15%)×85 | AC | 0. |
| | 100 × | 100. |
| | 15 % | GRAND TOTAL 15.00 |
| | | GRAND TOTAL 85.00 |



### 4. Memory function

| Arithmetic | Operation | Display |
|---|---|---|
| Example | | |
| (10×3)+(4×6)×(3÷4)÷39.25 | AC | 0. |
| | 10 × | 10. |
| | 3 M | GRAND TOTAL 30.00. |
| | 4 | GRAND TOTAL 4. |
| | 6 M | GRAND TOTAL 10.00 |
| | 3 ÷ | GRAND TOTAL 3. |
| | 4 M | GRAND TOTAL 0.75 |
| | MR | GRAND TOTAL 39.25 |
| | MC | 39.25 |

Note:

One-pressing on MRC key is MR function, and two-pressing is MC function

### 5. GT Totalize

Example

| | | |
|---|---|---|
| (1) 0.15+0.12÷0.27 | AC | 3. |
| | 0.15 | 0.15 |
| | 0.12 | GRAND TOTAL 0.27 |
| (2) 7×60%×4.2 | × | GRAND TOTAL 7. |
| | 60 % | GRAND TOTAL 4.2 |
| (3) 50÷2÷25 | 50 ÷ | GRAND TOTAL 50. |
| | 2 | GRAND TOTAL 25.00 |



| Arithmetic | Operation | Display |
|---|---|---|
| (4) 0.78 0.2 0.58 | 0.78 | GRAND TOTAL 0.78 |
| | 0.2 | GRAND TOTAL 0.58 |
| | GT | GRAND TOTAL 30.05 |
| (1) (2) (3) (4) 30.05 | AC | GRAND TOTAL 0. |

### 6.Constant function

The numbers behind operator are set as constant in arithmetic

| Arithmetic | Operation | Display |
|---|---|---|
| Example | | |
| (1) 5 6 11 ( 6 is constant ) | AC 5 | 5. |
| | 6 | GRAND TOTAL 11.00 |
| 9 6 15 | 9 | GRAND TOTAL 15.00 |
| 47 6 53 | 47 | GRAND TOTAL 53.00 |
| (2) 15 8 7 ( 8 is constant ) | AC 15 | 15. |
| | 8 | GRAND TOTAL 7.00 |
| 90 8 82 | 90 | GRAND TOTAL 82.00 |
| 41 8 33 | 41 | GRAND TOTAL 33.00 |
| (3) 27÷3÷9 ( 3 is constant ) | AC 27 ÷ | 27. |
| | 3 | GRAND TOTAL 9.00 |
| 330÷3÷110 | 330 | GRAND TOTAL 110.00 |
| 58.8÷3÷19.6 | 58.8 | GRAND TOTAL 19.60 |



| Arithmetic | Operation | Display |
|---|---|---|
| (4) 23×78÷1794 ( 23 is constant ) | AC 23 × | 23. |
| | 78 | GRAND TOTAL 1794.00 |
| 23×150×3450 | 150 | GRAND TOTAL 3450.00 |
| 23×8.41×193.43 | 8.41 | GRAND TOTAL 193.43 |

Notes: the numbers before operator are set as constant in multiplication arithmetic.

### 7. MU (elevation) function

Example: The cost of one good is $100.00. Calculate the selling price. If the profit is30%, how much should be the selling price? And how much is the profit? ( ÷ will be used.)

| | | |
|---|---|---|
| 100÷(1 30%)×142.86 ( Selling Price ) | 27 AC | 0. |
| 142.86×100×42.86 ( Profit ) | 100 | 100. |
| 42.86÷142.86÷30% | 30 MU | 142.86 |
| | MU | 42.86 |

Calculating cost. If the profit is 30%, how much should be the selling price? ( × will be used)

| | | |
|---|---|---|
| 100×(1 30%)×130 ( Selling Price ) | AC | 0. |
| 130×100×30 ( Profit ) 30÷100÷30% | 100 × 30 MU | 130.00 |



### 8. Correction and shift function

| Arithmetic | Operation | Display |
|---|---|---|
| 123×456÷(-78) 719.08 | 5 AC | 0. |
| | 123 × | 123. |
| | 445(wrong) | 445. |
| | 47 CE | 0. |
| | 15 ÷ | 56088. |
| | 77(wrong) | 77. |
| | ► | 7. |
| | 8 / | -78. |
| | | GRAND TOTAL -719.08 |
| | ► | GRAND TOTAL -719.00 |
| | OFF | |

Notes: CE Key clear the whole number. ► clear the last digit

Note: If the function discription of some models is not same with user manual, please subject to actual functions of device.



## ENGLISH

### ⚠ WARNING

Avoid use and storage of the calculator in areas subjected to temperature extremes and large amounts of humidity and dust.
Do not subject the calculator to excessive impact, pressure or bending.
Never try to open the calculator.
Use a soft, dry cloth to clean the exterior of the calculator.

### ⚠ BATTERY

Keep batteries out of the reach of small children.
Use only the type of battery specified for this calculator.
Even if the calculator is operating normally, replace the battery at least once every two years.
A battery can leak causing damage the calculator.

### PRODUCT RECYCLING

This symbol indicates that this product should not be disposed of with other household waste. Uncontrolled disposal of waste with environmental and public health risks, please separate your used products from other waste. You will thus promote the recycling of the material which composes them within the framework of a sustainable development.

Distributed by:
Wonday - Allée des acacias - 63190 LEZOUX - France
email : contact@wonday.com - web : www.wonday.com